

ATTENZIONE!

Togliere la corrente prima di eseguire qualsiasi collegamento elettrico o sostituire le lampadine.

- 1) Infilare il paralume mediante la rondella forata **1** bloccandolo con la bussola **2**.
- 2) Avvitare la lampadina.

Se il cavo flessibile di questo apparecchio viene danneggiato, deve essere sostituito da personale qualificato al fine di evitare pericoli

]

WARNING!

Switch off the current before connecting or relamping.

- 1) Insert the shade using the holed washer **1** and fix it with the lock nut **2**.
- 2) Screw the bulb.

If the external cable or cord is damaged, it shall be exclusively replaced by a qualified person in order to avoid a hazard.

]



(USA) WARNING!

Switch off the current before connecting or relamping.

- 1) Insert the shade using the holed washer **1** and fix it with the lock nut **2**.
- 2) Screw the bulb.

If the external cable or cord is damaged, it shall be exclusively replaced by a qualified person in order to avoid a hazard.

]



Eva

Lampada da terra/Floor lamp

r	7058/IC/BB	r	7058/IC/NN
r	7058/RS/BB	r	7058/RS/NN
r	7058/VI/BB	r	7058/VI/NN

Altezza/height	150cm – 59 1/2”
Ø/diameter	380cm – 15”
Peso/weight	22 Kg – 48 lb

r 100 - 120V	r 220- 240V
50Hz ~ 60Hz	

r N° 1 x max 100 W
r E27 r E26 (medium base)
Cl. I

