

**I) ATTENZIONE!**

**Togliere la corrente prima di eseguire qualsiasi collegamento elettrico o sostituire le lampadine.**

- 1) Fissare la catena **A** al gancio **B** e far passare il cavo elettrico lungo gli anelli della catena fino ad uscire dal gancio **C**.
- 2) Fissare al soffitto il gancio **C** ed effettuare il collegamento elettrico alla linea di alimentazione. Alzare il rosone **D** bloccandolo con la relativa vite.
- 3) Montare il disco in vetro tramite la borchia **E**.
- 4) Fissare con le apposite viti le palmette in vetro partendo dal livello più basso.



**(GB) WARNING!**

**Switch off the current before connecting or relamping.**

- 1) *Fasten the chain **A** to the hook **B** and slip the electrical wire in the chain's rings up to the hook **C**.*
- 2) *Affix the hook **C** to the ceiling and make the electrical connections to the power line. Lift the canopy **D** and lock it with the proper screw.*
- 3) *Fasten the glass plate with the stud **E**.*
- 4) *Assemble the glass elements with the proper screws starting from the lower level.*




**(USA) WARNING!**

**Switch off the current before connecting or relamping.**

**DO NOT ATTACH TO OUTLET BOX, FIXTURE OVER 50 POUNDS.**

- 1) *Fasten the chain **A** to the hook **B** and slip the electrical wire in the chain's rings up to the hook **C**.*
- 2) *Affix the hook **C** to the ceiling and make the electrical connections to the power line. Lift the canopy **D** and lock it with the proper screw.*
- 3) *Fasten the glass plate with the stud **E**.*
- 4) *Assemble the glass elements with the proper screws starting from the lower level.*



**Sospensione – Suspension lamp PALMETTE**

☐ 5310/9

**Altezza/height** 58cm – 23”  
**Ø/diameter** 64,5cm – 25½”  
**Peso/weight** 27 Kg – 59 lb

☐ 120V ☐ 240V  
50Hz ~ 60Hz

☐ N° 6x max 60W ☐ N° 6x max 40W

☐ E12 ☐ E14

**Cl. I**

Lampadina chiara / clear bulb



Agg.: 03/10/2016