

I) ATTENZIONE!

Togliere la corrente prima di eseguire qualsiasi collegamento elettrico o sostituire le lampadine.

- 1) Fissare la catena **A** al gancio **B** e far passare il cavo elettrico lungo gli anelli della catena e farlo uscire dal gancio **C**.
- 2) Agganciare al soffitto il gancio **C** ed effettuare il collegamento elettrico alla linea di alimentazione, alzare quindi il rosone **D** bloccandolo con la sua vite.
- 3) Fissare il disco in vetro con la borchia **E**.
- 4) Fissare con le apposite viti le palmette in vetro partendo dal livello più basso.



(GB) WARNING!

Switch off the current before connecting or relamping.

- 1) Fasten the chain **A** to hook **B** and make the electric wire run along the rings of the chain and go out from hook **C**.
- 2) Fix the hook **C** to the ceiling and make the electric connection to power line, lift the canopy **D** and lock it with the proper screw.
- 3) Fasten the glass plate with the stud **E**.
- 4) With the proper screws fasten the glass elements "palmette" starting from the lower level.




(USA) WARNING!



Switch off the current before connecting or relamping.

DO NOT ATTACH TO OUTLET BOX, FIXTURE OVER 50 POUNDS.

- 1) Fasten the chain **A** to hook **B** and make the electric wire run along the rings of the chain and go out from hook **C**.
- 2) Fix the hook **C** to the ceiling and make the electric connection to power line, lift the canopy **D** and lock it with the proper screw.
- 3) Fasten the glass plate with the stud **E**.
- 4) With the proper screws fasten the glass elements "palmette" starting from the lower level.



ONLY FOR USA



Lampadario PALMETTE

☐ 5310/7

h. cm 52 – 20" ½
Ø cm 90 – 35" ½
Kg. 45 – 99 pounds
☐ 100-120V ☐ 220-240V
 50Hz~60Hz
☐ N° 11x max 60W ☐ N° 11x max 40W
☐ E27 ☐ E26 (medium base)
Cl. I
 Lampadina chiara / clear bulb

