

(I) **ATTENZIONE!**

Togliere la corrente prima di eseguire qualsiasi collegamento elettrico o sostituire le lampadine.

- 1) Fissare la montatura al soffitto per mezzo della **staffa**.
- 2) Eseguire i collegamenti elettrici alla linea di alimentazione.
- 3) Montare le **foglie**.
- 4) Inserire il **fondino** ed avvitare il **finale**.

*

(GB) **WARNING!**

Switch off the current before connecting or relamping.

- 1) Hook the **clamp** to the ceiling.
- 2) Make up the electric connection to the main line feed.
- 3) Insert the **leaves** into the proper holes.
- 4) Slip the **bowl** and screw the glass **final**.

*



(USA) **WARNING!**

Switch off the current before connecting or relamping.

DO NOT ATTACH TO OUTLET BOX, FIXTURE OVER 50 POUNDS

- 1) Hook the **clamp** to the ceiling.
- 2) Make up the electric connection to the main line feed.
- 3) Insert the **leaves** into the proper holes.
- 4) Slip the **bowl** and screw the glass **final**.

*



Plafoniera

- 6744/BB
- 6744/BA
- 6744/BQ
- 6744/BG

SPADE

- 6744/CR
- 6744/OR-CR
- 6744/VR-CR
- 6744/RR-CR
- 6744/GR

altezza/height cm 48 - 19 "

Ø cm 78 - 30 "

peso/weight 32 Kg - 78.8 pounds

• 100V • 120V • 220V • 240V
50Hz~60Hz

N° 8 x max 60W + 2 x max 40W

• E14 • E17 • E12 (candelabra base)

• B15

Cl. I

Lamapdina opalina / White bulb



Agg: 26/01/2006