

(I) **ATTENZIONE!**

Togliere la corrente prima di eseguire qualsiasi collegamento elettrico o sostituire le lampadine.

- 1) Fissare la montatura al soffitto per mezzo della **staffa**.
- 2) Eseguire i collegamenti elettrici alla linea di alimentazione.
- 3) Montare le **foglie**.
- 4) Inserire il **fondino** ed avvitare il **finale**.

*

(GB) **WARNING!**

Switch off the current before connecting or relamping.

- 1) Hook the support to the ceiling with the **clamp**.
- 2) Make the electric connection to the main line feed.
- 3) Insert the **leaves** into the proper holes.
- 4) Slip the **bowl** and screw the glass **final**.



*

(USA) **WARNING!**

Switch off the current before connecting or relamping.
Do not attach to outlet box, fixture over 50 pounds

- 1) Hook the support to the ceiling with the **clamp**.
- 2) Make the electric connection to the main line feed.
- 3) Insert the **leaves** into the proper holes.
- 4) Slip the **bowl** and screw the glass **final**.

*



Sospensione **SPADE**

p 6746/BB
p 6746/BA
p 6746/BQ
p 6746/BG

altezza/height cm. 100 – 39 3/8”
Ø cm. 78 – 30 3/4”
peso/weight 53 – 116,6 pounds
p 100V p 120V p 220V p 240V
50Hz~60Hz
N° 9 x max 60W + 2 x max 40W
p E14 p E17 p E12 (candelabra base)
p B15
Cl. I

Lampadina opalina / White bulb



Agg: 26/01/2006